

Air Fried Bacon

Original bacon: Put bacon on a tray (or in the basket of air fryer) but make sure they are not overlapping. Air fry on 400 for 10 minutes. Drain on paper towels.

Candied bacon: cover each piece of bacon with a tablespoon of brown sugar. Air fry on 400 for 10 minutes and drain on paper. Be sure to clean your tray/basket immediately after every batch of candied.

Sriracha bacon: cover each piece of bacon with Sriracha and air fry on 400 for 5 minutes, then flip over and go the remaining 5. Drain on paper.

Garlic bacon: cover each piece of bacon with minced garlic and air fry at 400 for 10 minutes. Drain on paper.